

MOTOROLA

MODEL	MANUAL-PAGE	SEC.	MODEL	MANUAL-PAGE	SEC.	MODEL	MANUAL-PAGE	SEC.	MODEL	MANUAL-PAGE	
MOTOROLA INC. (Cont'd)			MOTOROLA INC. (Cont'd)			MOTOROLA INC. (Cont'd)			MOTOROLA INC. (Cont'd)		
Y21K23A, Ch. QTS-525Y,			Y21T14E, Ch. TS-507Y,	See 13-1		Y27K2, Y27K2B, Ch.			16VF8B, 16VFB8R, Ch. TS-16,		
	See 14-9		Y21T15, Ch. WTS-518Y	14-1		TS-602Y	13-12		TS-16A		4-30
Y21K23B, Ch. TS-528Y	14-9		Y21T16, Y21T16B, Y21T16E,			Y27K3, Ch. TS-602Y	13-12				5-8
Y21K23BA, Ch. QTS-525Y,			Ch. WTS-518Y	14-1		Y24K2, Y24K2B, Ch.			16VK1B, 16VK1R, Ch. TS-52	4-19, 20	5-1
	See 14-9		Y21T17, Y21T17B, Ch.			TS-602Y	13-12				
Y21K24, Ch. TS-528Y	14-9		VTS-518Y	14-1		TVT1, TVT2, TVT5, Ch.			16VK7B, 16VK7R, Ch. TS-16,		4-30
Y21K24A, Ch. QTS-525Y,	See 14-9		Y21T18, Y21T18B, Ch.	14-9		TS-18, TS-18A	4-11, 12		TS-16A		5-8
Y21K26, Ch. VTS-518Y,	14-9		RTS-525Y	14-9		9L1, Ch. TS-18, TS-18A	4-11, 12				
	Same as page 14-1		Y21T19, Ch. TS-528Y	14-9			C7-2		17F1, Ch. TS-118		7-35
Y21K26B, Ch. VTS-518Y,			Y21T19A, Ch. QTS-525Y,	See 14-9		10T2, Ch. TS-14B	4-19, 20		17F1, Ch. TS-118A, TS-118B	9-25	
	See 14-9		Y21T19B, Ch. TS-528Y	14-9			5-1		17F1A, Ch. TS-89		7-17
Y21K27, Ch. RTS-525Y,	See 14-9		Y21T19B, Ch. QTS-525Y,	See 14-9		10VK9, Ch. TS-9E, TS-901	3-18		17F1B, Ch. TS-118		7-35
Y21K27B, Ch. RTS-525Y,	See 14-9					10VK12, 10VK12R, 10VK22R,			17F1BA, Ch. TS-89		7-17
Y21K28, Ch. WTS-525Y,	See 14-9		Y21T21, Y21T21B, Y21T21E,			Ch. TS-14, TS-14A, TS-14B	4-19, 20		17F2W, Ch. TS-118		7-35
Y21K28B, Ch. WTS-525Y,	See 14-9		Ch. WTS-531Y	15-1			5-1		17F2W, Ch. TS-118A, TS-118B	9-25	
Y21K29, Y21K29B, Y21K29W,			Y21T22, Y21T22B, Ch.			10VT3, Ch. TS-9E, TS-901	3-18		17F2WA, Ch. TS-89		7-17
Ch. WTS-531Y	15-1		TS-531Y	15-1		10VT10, 10VT10B, 10VT10R,			17F3B, Ch. TS-118		7-35
Y21K30, Y21K30B, Ch.			Y21T23, Y21T23B, Ch.			Ch. TS-14, TS-14A, TS-14B	4-19, 20		17F3B, Ch. TS-118A, TS-118B	9-25	
TS-531Y	15-1		TTS-525Y,	See 14-9			5-1		17F3BA, Ch. TS-89		7-17
Y21K30W, Ch. TS-531Y,			Y21T24, Y21T24B, Ch.			10VT24R, Ch. TS-14, TS-14A,			17F4, Ch. TS-118		7-35
	See 14-9		QTS-525Y,	See 14-9		TS-14B	4-19, 20		17F4, Ch. TS-118A, TS-118B	9-25	
Y21K31, Y21K31B, Ch.			Y-21T25CH, Y-21T25PK,				5-1		17F4A, Ch. TS-89		7-17
TTS-525Y,	See 14-9		Y-21T25TN, Ch. TS-530Y	17-1		12K1, Ch. TS-23B	4-19, 20		17F5, Ch. TS-118		7-35
Y21K32, Ch. QTS-525Y,	See 14-9		Y-21T26B, Y-21T26BA,				5-1		17F5, Ch. TS-118A, TS-118B	9-25	
Y21K32A, Ch. WTS-525Y,	See 14-9		Ch. TS-534Y	17-27		12K1, Ch. TS-53	6-1		17F5A, Ch. TS-89		7-17
Y21K32B, Ch. QTS-525Y,	See 14-9		Y-21T26CH, Y-21T26CHA,			12K1B, Ch. TS-23B	4-19, 20		17F5B, Ch. TS-118		7-35
Y21K32BA, Ch. WTS-525Y,	See 14-9		Ch. TS-534Y	17-27			5-1		17F5BA, Ch. TS-89		7-17
Y21K33E, Ch. WTS-531Y,			Y-21T27B, Ch. TS-534Y	17-27		12K1B, Ch. TS-53	6-1		17F6, Ch. TS-118		7-35
	See 14-9		Y-21T27MA, Ch. TS-534Y	17-27		12K2, Ch. TS-23B	4-19, 20		17F6B, Ch. TS-118		7-35
Y-21K37B, Y-21K37BA,			Y-21T27PK, Ch. TS-534Y	17-27			5-1		17F7, Ch. TS-118A, TS-118B	9-25	
Y-21K37BR, Y-21K37BRA,			Y-21T28, Y-21T28B, Ch.			12K2B, Ch. TS-23B	4-19, 20		17F7B, Ch. TS-118		7-35
Ch. TS-534Y	17-27		TS-534Y	17-27			5-1		17F8, Ch. TS-118		7-35
Y-21K38, Y-21K38B, Ch.			Y21T-32B, Ch. TTS-537Y	19-1		12K2B, 12K3, 12K3B, Ch.			17F8C, Ch. TS-118A, TS-118B	9-25	
TS-530Y	17-1		Y21T32BA, Ch. TS-537Y	19-1		TS-53	6-1		17F9, Ch. TS-118		7-35
Y-21K39, Y-21K39B, Ch.			Y21T-32CH, Ch. TTS-537Y	19-1		12T1, Ch. TS-23B	4-19, 20		17F9B, Ch. TS-118		7-35
TS-534Y	17-27		Y21T-32CHA, Ch. TS-537Y	19-1			5-1		17F9B, Ch. TS-118A, TS-118B	9-25	
Y-21K40, Y-21K40B, Ch.			Y21T-32MGA, Ch. TTS-537Y	19-1		12T1, Ch. TS-53	6-1		17F9C, Ch. TS-118A, TS-118B	9-25	
TS-534Y	17-27		Y21T-33BG, Ch. TS-538Y	19-21		12T1B, Ch. TS-23B	4-19, 20		17F9C, Ch. TS-174, TS-174A	8-1	
Y-21K41, Y21K41B, Ch.			Y21T-33CH, Ch. TS-538Y	19-21			5-1		17F9C, Ch. TS-174, TS-174A	8-1	
TS-533Y	17-13		Y21T-33MG, Ch. TS-538Y	19-21		12T1B, 12T2, 12T3, Ch. TS-53	6-1		17F9C, Ch. TS-174, TS-174A	8-1	
Y-21K42, Y-21K42B, Ch.			Y21T-34B, Ch. TTS-537Y	19-1		12VF4B, 12VF4R, 12VF4R-C,			17F9, Ch. TS-118		7-35
TS-533Y	17-13		Y21T-34BA, Ch. TS-537Y	19-1		Ch. TS-23, TS-23A	4-19, 20		17F9, Ch. TS-118A, TS-118B	9-25	
Y-21K43, Y-21K43B, Ch.			Y21T-34M, Ch. TTS-537Y	19-1			5-1		17F9, Ch. TS-118A, TS-118B	9-25	
TS-533Y	17-13		Y21T-34MA, Ch. TS-537Y	19-1		12VF26B, 12VF26B-C,			17F9B, Ch. TS-118		7-35
Y-21K44B, Y-21K44W, Ch.			Y21T-35B, Ch. TS-538Y	19-21		12VF26R, 12VF26R-C,					
TS-533Y	17-13		Y21T-35M, Ch. TS-538Y	19-21		Ch. TS-23A, TS-23B	4-19, 20				
Y-21K45, Ch. TS-533Y	17-13		Y21T-36B, Ch. WTS-538Y	19-21			5-1		17F9C, Ch. TS-174, TS-174A	8-1	
Y21K45B, Ch. TS-534Y,			Y21T-36M, Ch. WTS-538Y	19-21		12VK11, 12VK11B, 12VK11R,			17F9C, Ch. TS-174, TS-174A	8-1	
	See 14-9		Y24K1, Y24K1B, Ch.			Ch. TS-23, TS-23A, TS-23B	4-19, 20		17F11, Ch. TS-228		10-1
Y21K48M, Ch. TS-534Y,			TS-602Y	13-12			5-1		17F12, Ch. TS-325		10-13
	See 14-9		Y24K3, Y24K3W, Ch.			12VK15B, 12VK15R, Ch.			17F12A, Ch. TS-326		10-13
Y21K-53B, Ch. TTS-537Y	19-1		TS-602Y	13-12		TS-30, TS-30A	5-8		17F12B, Ch. TS-325		10-13
Y21K-53BA, Ch. TS-537Y	19-1		Y24K4, Y24K4B, Ch.			12VK16, Ch. TS-15, TS-15A,			17F12B, Ch. TS-325		10-13
Y21K-53M, Ch. TTS-537Y	19-1		TS-603Y	14-9		TS-15B, TS-15C, TS-15C1	3-26		17F12B, Ch. TS-325		10-13
Y21K-53MA, Ch. TS-537Y	19-1		Y24K5, Y24K5B, Ch.			12VT13, 12VT13B, 12VT13R,			17F12B, Ch. TS-326		10-13
Y21K-54B, Ch. TS-538Y	19-21		TS-603Y	14-9		Ch. TS-23, TS-23A, TS-23B	4-19, 20		17F12D, Ch. TS-401		10-13
Y21K-54M, Ch. TS-538Y	19-21		Y24K7, Y24K7B, Ch.				5-1		17F13, 17F13B, Ch. TS-395A, TS-395A-01, TS-395A-02		11-19
Y21K-55B, Ch. TTS-537Y	19-1		TS-603Y,	See 14-9		12VT16, Ch. TS-15, TS-15A,			17F13BC, Ch. TS-408A,		12-11
Y21K-55BA, Ch. TS-537Y	19-1		Y-24K9, Y-24K9B, Ch.			TS-15B, TS-15C, TS-15C1	3-26		B Series		
Y21K-55M, Ch. TTS-537Y	19-1		TS-534Y	17-27		14K1, 14K1B, Ch. TS-88	6-29, 30		17F13BCY, Ch. TS-408Y		12-11
Y21K-55MA, Ch. TS-537Y	19-1		Y-24K10, Y-24K10B, Ch.			14K1BH, 14K1H, Ch. TS-115	6-16		17F13C, Ch. TS-408A,		12-11
Y21K-56B, Ch. WTS-538Y	19-21		TS-533Y	17-13		14PB, Ch. TS-216,			B Series		
Y21K-56M, Ch. WTS-538Y	19-21		Y-24K11, Y-24K11B, Ch.				9-1		17F13CY, Ch. TS-408Y		12-11
Y21K-57B, Ch. WTS-538Y	19-21		TS-533Y	17-13		14P2, Ch. TS-275	11-33	III	17F13F, Ch. TS-408		12-11
Y21K-57M, Ch. WTS-538Y	19-21		Y24K-13B, Ch. WTS-537Y	19-1		14P2U, Ch. TS-275,			17F13FY, Ch. TS-408Y Series 12-11		
Y21K-57MCH, Ch. WTS-538Y	19-21		Y24K-13M, Ch. WTS-537Y	19-1			Same as page 11-33		17F13FY, Ch. TS-408Y Series 12-11		
Y21K-58B, Ch. WTS-538Y	19-21		Y24K-14B, Ch. WTS-538Y	19-21		14T1, 14T1B, Ch. TS-88	6-29, 30		17K1A, 17K1BA, Ch. TS-95		7-17
Y21K-58M, Ch. WTS-538Y	19-21		Y24K-14M, Ch. VTS-538Y	19-21		14T4, 14T4B, Ch. TS-216	6-42		17K1B, 17K1R, 17K22B,		
Y21K-59M, Ch. VTS-538Y	19-21		Y24T2, Y24T2B, Ch.				7-1		17K2E, Ch. TS-172		7-46
Y21K-59MCH, Ch. VTS-538Y	19-21		TS-609Y	15-1		16F1BH, 16F1H, Ch. TS-89	7-17		17K3, Ch. TS-118		7-35
Y21T8A, Y21T8AE, Ch.			Y-24T3BR, Ch. TS-534Y	17-27		16K2, 16K2B, Ch. TS-74	6-51, 52		17K3, Ch. TS-118A, TS-118B	9-25	
TTS-502Y	13-1		Y-24T4, Y-24T4B, Ch.			16K2BH, 16K2H, Ch. TS-94	7-17		17K3A, Ch. TS-89		7-17
Y21T10, Ch. VTS-505Y,	See 13-1		TS-533Y	17-13		16K2L, 16K2LB, Ch. TS-52	4-19, 20		17K3B, Ch. TS-118		7-35
Y21T11, Y21T11B, Y21T11W,			Y24T-58G, Ch. WTS-537Y	19-1			5-1		17K3BA, Ch. TS-89		7-17
Ch. VTS-502Y	13-1		Y24T-58G, Ch. WTS-537Y	19-1		16T1, 16T1B, Ch. TS-80	7-1		17K4A, Ch. TS-95		7-17
Y21T13, Y21T13B, Ch.			Y24T-6M, Ch. VTS-538Y	19-21		16T1BH, 16T1H, Ch. TS-89	7-17		17K4E, Ch. TS-172		7-46
TS-524Y,	See 13-1										