



RCA Victor

TELEVISION CONSOLE

Model

TRK-9

Reproduces Television Pictures
with Sound

Direct Viewing

36 Tubes plus 9" Kinescope

5 Television Channels

5½" x 7¼" Black and White
Pictures

Single Station Selector Switch for
Both Picture and Sound

12-Tube, 3-Band All-Wave
Radio Chassis

Victrola Switch

12-Watt Push-pull Output

12" Super-Fidelity Speaker

High-Fidelity Sound

The RCA Victor Television Console Model TRK-9 is a deluxe Television receiver complete with High-Fidelity 12-tube, 3-band RCA Victor Radio. The picture is viewed directly from the front of the cabinet and operation is simplified by means of handy controls.

For those who want an excellent Television receiver plus the finest in radio, the RCA Victor Model TRK-9 will be found to be the logical choice. It is housed in an attractive modern-type console cabinet.

OTHER FEATURES

Television: Styrol R-F and I-F Transformers; Temperature-compensated Condensers; Iron Core Tuning for R-F and I-F Transformers; Double-safety Switch Protection; Fire Underwriters' Approval.

Radio: Improved Electric Tuning (9 stations); Deluxe Streamline Dial; Magic Eye; Band Indicator; 4-Point Tone Control (radio); 3-Point Tone Control (Victrola); 2-Point Automatic Tone Compensation; Automatic Volume Control; Magnetite Frequency-locking I-F Transformers; Inverse Feedback; Feedback On-off Switch; High-Fidelity 12-watt Output.

CABINET: A deluxe upright modern cabinet, hand-polished to a high gloss finish. The front is center-matched butt walnut, with a striped walnut band in bottom of front panel. The Kinescope frame is dark butt walnut while the top and sides are of heart walnut. Cabinet blends harmoniously with the finest of living rooms. Height 47¼", Width 31½", Depth 24¾".

TUNING RANGE

Television: 5 Bands—44-50 Mc., 50-56 Mc., 66-72 Mc., 78-84 Mc., 84-90 Mc.

Radio: 540-1720, 2300-7,000, 7,000-22,000 Kcs.

TUBE COMPLEMENT

Television: 2 RCA 6J5; 3 RCA 1852; 5 RCA 1853; 1 RCA 6SK7; 3 RCA 6H6; 1 RCA 6F8G; 4 RCA 6N7; 1 RCA 6Y6G; 1 RCA 6L6; 1 RCA 5V4G; 1 RCA 5T41; 1 RCA 2V3G; 1 RCA 1804-P4.

Radio: 3 RCA 6K7; 1 RCA 6A8; 1 RCA 6J7; 1 RCA 6R7; 2 RCA 6J5; 2 RCA 6F6; 1 RCA 5U4G; 1 RCA 6U5.